

1 DESCRIPTION

The NFS3030 Serial driver allows the FieldServer to record data from Notifier Onyx Series NFS3030 Fire Panels over RS-232.

The FieldServer acts as a Passive Client receiving messages and recording the status of a Notifier 3030 Fire Alarm Panel. There is no active polling by this driver; the communications are one-way through the panel's printer port.

This driver is not capable of emulating a Notifier NFS3030 panel and the very limited Server functionality has only been implemented to facilitate FieldServer's Quality Assurance program.

The purpose of this driver is to record the status of Fire Alarm System detectors and Modules in Data Arrays - one Data Array per loop. It is limited by the information that the Notifier NFS3030 unit sends in the form of text messages through its RS-232 printer port. The accuracy and timeliness of the data is therefore limited to the frequency of update messages that the Notifier Fire Panel issues.

Appendix A lists the Notifier message types supported by this driver and the effect on the status of points in the Data Array. The driver is capable of supporting the panel's port supervision message if configured to do so.

The panel must output messages in English.

1.1 Connection Facts

FieldServer Mode	Nodes	Comments
Client	1	Each FieldServer port can connect to only 1 NFS3030 panel
Server	0	The NFS3030 driver cannot be used as a Server

2 FORMAL DRIVER TYPE

Serial

Passive Client

3 COMPATIBILITY

FieldServer Model	Compatible
FS-B35 Series	Yes
ProtoNode/ProtoAir	Yes
QuickServer FS-QS-10xx	No
QuickServer FS-QS-12xx	Yes
QuickServer FS-QS-20xx	No
QuickServer FS-QS-22xx	Yes

4 CONNECTION INFORMATION

Connection Type: RS-232 (Vendor Limitation)
 Baud Rates: 9600 (Vendor Limitation)
 Data Bits: 8 (Vendor Limitation)
 Stop Bits: 1 (Vendor Limitation)
 Parity: None (Vendor Limitation)
 Multidrop Capability: No

5 DEVICES TESTED

Device	Tested (FACTORY, SITE)
NFS-3030 Test Panel supplied by Notifier Corp.	Factory
BOOT: 002.003.002 APP: 002.003.014	Site
BOOT: 002.012.006 APP: 002.013.002	Site

6 COMMUNICATION FUNCTIONS

6.1 Data Types Supported

This driver was designed to be connected to the Notifier Onyx NFS-3030 printer port and listen for incoming messages. The panel's default setting for the printer port is off. To utilize this driver, the printer port must be enabled to 80-columns, unsupervised, before this driver can be used.

The primary purpose of this driver is to record the status of devices connected to the NFS-3030 system by interpreting the text messages sent to the printer port. Not all messages will be interpreted, as many messages do not directly pertain to device status or are currently supported. The following subset of event messages is recognized:

Active Events
FIRE ALARM
TROUBLE
PREALARM
SECURITY ALARM
SUPERVISORY
DISABLED
ON/OFF <i>detectors, modules, panels only</i>
ACTIVE

A detailed mapping of message interaction System Trouble messages provided by Notifier at the time this driver was written is tabulated in the NFS 3030 Driver Manual. Any changes or additions by Notifier will not be reflected in this driver unless specifically revised.

6.2 Zone Status

Information about zone status that is incorporated with point status messages will not be recorded by this driver. A device can belong to multiple zones; however, only the primary zone is listed in printer output. This severely limits the accuracy of zone data based on event generated messages, and therefore will not be recorded.

However, zone DISABLED messages will be recorded by the driver as there is no ambiguity in their status.

6.3 Panel Status: Data Array Mapping

The status of NFS 3030 devices will be recorded into a series of data arrays within the FieldServer and are available for reading by any other connected device. The data from each loop will be recorded into a separate data array, and a single system array will record system troubles and disabled zones. The structure of the data arrays is provided below.

Most of these arrays will only contain binary information to represent an active or inactive state. However, there could be multiple troubles associated with a single device. For each trouble message, the data array register corresponding to a particular device will be incremented as a counter and decremented when a trouble is cleared.

Parameter	Registers (float)	
<i>{per loop}</i>		
Fire Alarm	0-199	detectors
	200-399	modules
Trouble - <i>each point increments/decrements the troubles recorded, system normal will reset the counter to 0</i>	500-799	detectors
	700-899	modules
PreAlarm	1000-1199	detectors
	1200-1399	modules
Security Alarm	1500-1799	detectors
	1700-1899	modules
Supervisory	2000-2199	detectors
	2200-2399	modules
Disabled	2500-2799	detectors
	2700-2899	modules
On/Off	3000-3199	detectors
	3200-3399	modules
Active	3500-3799	detectors
	3700-3899	modules
<i>{system points only}</i>		
System Troubles	0-1000	
Disabled Zones	1000-1999	General Zones
	2000-2099	Releasing Zones
	2100-2199	Trouble Zones
Panel	3000-3099	Fire Alarm
	3100-3199	Trouble
*note: some of these Data Arrays are not appropriate for panels but arranged in this fashion for symmetry in message parsing	3200-3299	*
	3300-3399	Security Alarm
	3400-3499	*
	3500-3599	Disabled
	3600-3699	On/Off
	3700-3799	*

6.4 Driver Limitations & Exclusions

- Zone information will not be recorded.
- To synchronize the FieldServer with the panel, connect the running FieldServer and press the “System Reset” button on the panel. All current events will be re-sent to the FieldServer.
- The port must be enabled on the unit and set to 80 columns with NO supervision
- All data related to non-event driven reports will not be recorded by the FieldServer
- This driver was written as a subset of *NFS2-3030/NCA-2 EIA-232 Protocol & Data Formats* 53219 Rev A 1/3/2008. Any changes or additions by Notifier will not be reflected in this driver unless specifically revised.
- This driver will not record information about zone status that is incorporated with point status messages.
- There can only be one panel connected to any given FieldServer port.
- This driver records data as presented to the printer/CRT port by the Notifier panel and can only be as accurate as this data.
- The driver cannot send messages to the Notifier panel.
- Driver will clear any data on “System Normal” only if this data is previously set by driver and is not yet cleared by “Cleared” message and is configured to `Clear_on_Normal`. By default, `Clear_on_Normal` is “yes”.

Driver will clear any Node data on “System RESET” only if this data is previously set by driver and is not yet cleared by “Cleared” message and is configured to `Clear_on_Reset`. By default, `Clear_on_Reset` is “no”.