

1 DESCRIPTION

The Hanning & Kahl HCS-R driver allows the transfer of data from devices over RS-232 HCS-R protocol. Data is read from HCS-R and current data stored in a specified memory area. The driver can store the data with its loop data status in distinct memory areas depending on whether the data is on loop or from loop. The driver is based on section 10.5 of Hanning & Kahl - part number 40801121. The FieldServer can act as a Client or Server.

1.1 Connection Facts

FieldServer Mode	Nodes	Comments
Client	1	Only 1 virtual client per port allowed on Multidrop systems
Server	1	This is a protocol limitation

2 FORMAL DRIVER TYPE

Serial

Client or Server

3 COMPATIBILITY

FieldServer Model	Compatible
FS-B35 Series	Yes
ProtoNode/ProtoAir	Yes
QuickServer FS-QS-10xx	No
QuickServer FS-QS-122x	Yes
QuickServer FS-QS-20xx	No
QuickServer FS-QS-22xx	Yes

4 CONNECTION INFORMATION

Connection Type: RS-232
 Baud Rates: 9600 (Vendor Limitation)
 Data Bits: 8 (Vendor Limitation)
 Stop Bits: 1 (Vendor Limitation)
 Parity: None (Vendor Limitation)
 Multidrop Capability: Yes

5 DEVICES TESTED

Device	Tested (FACTORY, SITE)
HCS-R-R"– part # "44.745.033	SITE

6 COMMUNICATION FUNCTIONS

6.1 Data Types Supported

FieldServer Data Type	Description (or Device Data Type)
Digital Input	Data bits
	Loop number and loop status

6.2 Read Operations Supported

FieldServer as a Client	FieldServer as a Server
Poll (including Sync and Acknowledge)	Response along with loop number and status