



FieldServer ENOTE

ProtoNode, ProtoCarrier or ProtoCessor Recovery Instructions



Document Revision: 1.A
Date: 7/18
T18020

1 WHEN TO PERFORM A RECOVERY

Perform the following recovery if unable to connect to a FieldServer.


The following recovery instructions only apply to FieldServer ProtoNodes, ProtoCarriers or ProtoCessors of model type 2.

If the FieldServer was received before June 2018, the FieldServer is model type 1. However, model type 1 FieldServers are still being shipped so a visual check of the ProtoCessor board is needed to confirm the model type of a FieldServer. Check the images below for confirmation of the FieldServer model type.




2 RECOVERY INSTRUCTIONS

- Put a jumper on the first and second pins shown on the left side of the Ethernet port as shown below:



- Wait for 1 to 2 minutes for the Run LED to start flashing.

NOTE: See Run LED location below:



- When the Run LED starts flashing, remove the jumper.
- The unit IP Address will be set to 192.168.2.100.
- Open a browser window on a PC connected to the local network and download the config/firmware/img files for the application.

Technical Support

Thank you for purchasing the FieldServer from Sierra Monitor Corporation.

Please call us for any technical support needs related to the FieldServer product.

Sierra Monitor Corporation
1991 Tarob Court
Milpitas, CA 95035

Website: www.sierramonitor.com

U.S. Support Information:

+1 408 964-4443

+1 800 727-4377

Email: support@sierramonitor.com

EMEA Support Information:

+31 33 808 0590

Email: support.emea@sierramonitor.com